

VAJA 9: Merjenje odbojnosti antene z mostičnim reflektometromVhodna moč v mostiček: $P_0 =$ **Meritve:**

f [MHz]	Kratkostičnik		Prilagojeno breme		Merjena antena	
	P [dBm]	$ \Gamma $ [dB]	P [dBm]	$ \Gamma $ [dB]	P [dBm]	$ \Gamma $ [dB]
100						
200						
300						
400						
500						
600						
700						
800						
900						
1000						
1100						
1200						
1300						
1400						
1500						
1600						
1700						
1800						
1900						
2000						

Grafi:

